



Personal Power Pack Jump Starters

TP001

USER MANUAL

Tyre Pump 0 - 80 psi
For use with
All model SJS Power Packs



SMART JUMP STARTERS PTY LTD

www.smartjumpstarters.com.au

Australian Owned and Operated

**Thank you for purchasing the TP001
tyre pump.**

**Please take the time to read this
manual so that you can correctly use
the tyre pump and all of its features.**

TYRE PUMP FEATURES & ACCESSORIES



- A . 2-Pin Power Lead Connector
- B. LED Light
- C. On/Off Switch
- D. Air Hose
- E. Pressure Gauge

This tyre pump is only suitable for use with all SJS power packs .
(If using SJS3000 use the EC85 adaptor included in the kit)



- Ball Inflation Adaptor
- Inflation Adaptor to suit camping mattresses etc.

These accessories screw into the screw fitting on the end of the air hose (D).

INSTRUCTIONS FOR USE

1. Check the battery charge level of your power pack by switching it on and noting the LCD screen or blue charge lights (depending on which model you have).
2. Connect the 2-pin power lead (A) to the 2-pin jump port on your power pack . The LED light (B) will illuminate.
3. Connect the air hose (D) to the air valve on the tyre to be inflated by screwing the air hose fitting securely onto the tyre valve .
4. Push the ON/OFF switch (C) once to turn the pump on and start tyre inflation.
5. The maximum run time for inflation of a tyre that is under 35 psi is 30 minutes. Less for higher pressure. If the tyre is not inflated to the desired pressure at 30 minutes, turn the pump off and let it cool for at least 15 minutes. Resume inflation once the pump has cooled.
6. Check the pressure on the pump gauge (E). When the tyre is inflated to the desired pressure, push the ON/OFF switch (C) once to turn the pump off. Remove the air hose from tyre valve by unscrewing the fitting. Turn off your power pack.
7. **ALWAYS CHECK YOUR TYRE PRESSURE WITH AN ACCURATE TYRE PRESSURE GAUGE.**

WARNING:

- Do not touch the air hose whilst the pump is in use. The air hose can get very hot.
- Always stand clear of the tyre or item being inflated.
- Always check your vehicle tyre guide or item user manual for recommended inflation pressures before starting.
- Never over-inflate a tyre or any other item beyond its recommended maximum pressure.

STORAGE AND MAINTENANCE

Please store your SJS Tyre Pump in a dry location away from moisture.

Do not use solvents or detergents of any kind to clean the device. Use a clean dry rag to wipe clean.

Treat the tyre pump with care. Dropping the device can cause damage.

SPARE PARTS:

- Ball inflation adaptor to suit sports equipment etc.
- Inflation adaptor to suit camping mattresses etc.

Please contact your local distributor for spare parts and accessories. Full details of available parts and accessories can be found on our website.

TECHNICAL SPECIFICATIONS:

Power Input:	12V DC via SJS Power Pack
Current Draw:	2.5 Amp (30W) to 6amp (72W)
Inflation Rate:	15 minutes to inflate tyre size 205/65R15 to 40 psi.
Max Run Time:	30 minutes from under 35 psi.
Cooling Time:	15 minutes before resuming inflation.
Max Pressure:	80 psi
Pressure Gauge:	Analogue, psi kPa, Bar.
Working Temp:	-10 deg C to + 60 deg C
Light:	LED
Dimensions:	108 mm x 95 mm x 45 mm
Weight:	300g

Power pack run times @ max 6 A draw: (in 15 minute intervals)

- SSC05 / SJS05G2 / SJS1200: 40 min
- SSC06 / SJS06G2:/ SJS1500 52 min
- SJS3000 96 mins

WARRANTY

The TP001 is covered by a 12 month warranty against manufacturing faults.

In the unlikely event that the TP001 has suffered a fault, it must be returned to the place of purchase and accompanied with proof of purchase so that it can be returned to Smart Jump Starters Pty Ltd for testing. If found to be faulty, the part will be replaced.

Smart Jump Starters Pty Ltd will not be liable for any freight charges as part of a warranty claim.

Smart Jump Starters Pty Ltd will not be liable for any consequential damage in the unlikely event this should occur.

WARRANTY EXCLUSIONS:

- The TP001 is not covered by warranty if any power source other than a genuine SJS power pack has been used to power the pump as this could lead to damage of the pump compressor.
- The TP001 is not covered by warranty if it has been misused, dropped onto a hard surface, exposed to water or damaged in any way by using the device outside of it's design parameters or not in accordance with instructions.
- The TP001 is not covered by warranty if the pump casing has been opened and the seals are broken., or the power cable or any part has been modified in any way.

For technical advice, please contact SJS directly:



Smart Jump Starters Pty Ltd
1/13 Commerce Avenue
Warana QLD 4575
AUSTRALIA
E: sales@autoglobe.com.au
Website: www.smartjumpstarters.com.au